

Contents

1. Introduction	2
1.1 Overview	
1.2 Main Features	
2. Safety/Precautions	3
2.1 Safety	
2.2 Precautions	
3. Check Point before Use	5
3.1 Accessories	
4. Controls/Functions	6
4.1 Front Panel	
4.2 Rear Panel	
4.3 Remote controller	
4.4 Front Display	
5. How to Connect	11
6. Operation	12
6.1 Getting Started	
6.2 System Setting	
6.3 Channel Manager	
6.4 Installation	
6.5 Utils	
6.6 Game	
6.7 Common Interface	
6.8 Conditional Access System	
6.9 PVR	
7. Trouble Shooting	58
8. Specifications	59


DiSEqC is a trademark of EUTELSAT

Introduction

1.1 Overview

This satellite receiver is designed for using digital free-to-air channel reception. Enjoy the rich choice of more than 10,000 different channels, broadcasting a large range of culture, sports, cinema, news, events, etc. This receiver is a technical masterpiece, assembled with the highest qualified electronic parts.


1.2 Main Features

- ▶ Compliant MPEG-II/ MPEG-IV/ H.264.
- ▶ 2 tuner combo (DVB-Satellite & DVB-Terrestrial)
- ▶ Compliant DVB-S/ S2 satellite standard & DVB-T standard
- ▶ Output resolution 576p & 576i, 720p, 1080i
- ▶ 1 HDMI output
- ▶ Multisatellite search.
- ▶ On-screen display with true color full resolution.
- ▶ DiSEqC control version 1.0, 1.1, 1.2 and USALS compatible.
- ▶ Enhanced 16 favorite channel groups.
- ▶ Powerful channel control by favorites, lock, skip, move and delete function.
- ▶ Channel sort by alphabet, transponder and CAS.
- ▶ Multilingual GUI (OSG & Menu): English, Russian, Deutsch.
- ▶ Installation wizard
- ▶ Extended EPG and program reservation on EPG.
- ▶ Teletext & Subtitle by OSD and VBI
- ▶ Last channel memory function.
- ▶ Total 10,000 channels programmable.
- ▶ Preprogrammed channels (Optional)
- ▶ Dolby digital audio output (S/PDIF)
- ▶ S-Video
- ▶ Component output (YPbPr)
- ▶ Various games
- ▶ Software & channel database upgrade via RS-232C: PC to STB/ STB to PC.
- ▶ Parental lock / Installation lock / receiver lock.
- ▶ Zoom in function on pause/ live channel
- ▶ Multipicture display.
- ▶ High speed software upgrade via USB 2.0
- ▶ MP3 play and JPEG viewer
- ▶ Support 2 USB Port on Front Panel & Rear Panel
- ▶ eSATA(External SATA Interface, 7200RPM support only)
- ▶ Lan 10/100Mbps Ethernet
- ▶  Manufactured under license from Dolby Laboratories.
"Dolby" and the double-D Symbol are trademarks of Dolby Laboratories.


Safety/Precautions

2.1 Safety


Be sure to read this user's manual before starting the operation of the unit.




Do not touch the power cord with wet hands as it may cause electric shock.




Never open the cover. It is very dangerous to touch the inside of the unit due to possible electric shock.




Place the unit in a well ventilated and no-heat environment.



When you do not use this unit for a long time, make sure that power cord is pulled out from the outlet. Also do not use a damaged power cord as it may cause fire or electric shock.




A professional installation is required. If reception is interrupted, contact your local service centre.




2.2 Precautions

When installing the unit

Install the unit horizontally. An uneven installation may cause the unit to be damaged.




Do not put heavy items such as a TV set on the unit. That may damage the unit.



Do not leave the unit where the water drops or splashes.




Do not put water holding items such as vases on the unit.




Do not install the unit:

- Where it is subject to vibrations
- Where it is exposed to direct sunlight
- Where there is humidity
- Where the temperature is too high or too low.
- Where there is no ventilation



Moving the unit to a hot area from a cold one will cause condensation. Do not operate the unit for one or two hours or until it has dried completely.




- The mains plug is used as the disconnect device. The disconnect device shall remain readily operable.

Points to Check before Use

3.1 Accessories

The accessories below are included with this receiver:


User's manual : 1



Remote control : 1



Batteries (AAA type) : 2



HDMI cable : 1



- If any of the above-listed accessories is missing, contact your sales representative.


3.2 The Satellite dish

Your dish should be properly installed and azimuth and elevation must be precisely set up.

- This unit supports DiSEqC 1.2 and can work with a compatible antenna positioner. Ask your dealer for information.


Controls/Functions

4.1 Front Panel




- 1 Power** : Switches the receiver between "Standby" and "Power ON" modes.
- 2 Menu** : To enter or exit the main menu.
- 3 Select** : To show the Channel List in non-menu mode and select on item or confirm in menu mode.
- 4 - 5 VOL** (◀/▶) : To change the volume level in non-menu mode and modify a setting in menu mode.
- 6 - 7 CH** (▼/▲) : To switch channels or change the cursor position on the application screen.

4.2 Rear Panel




No.	Name	Connector	Function
1	ANT IN	IEC 169-2 FEMALE	Input from terrestrial antenna
2	ANT OUT	IEC 169-2 MALE	Loop-through output from digital tuner and Output to TV
3	LNB INPUT	IEC 169-24 FEMALE	IF input from LNB to digital tuner
4	LNB OUTPUT	IEC 169-24 FEMALE	IF loop-through output from digital tuner
5	USB	USB A-type	USB 2.0
6	VCR/AUX SCART	SCART	CVBS Video Output CVBS, RGB Video Input Audio Output
7	TV SCART	SCART	Video output(CVBS, RGB) Audio output(R, L)
8	eSATA	E-SATA	External SATA
9	HDMI	HDMI	Digital Video/Audio Output
10	RS-232C	DB-9	Low speed serial port
11	LAN	RJ-45	10/100Mbps Ethernet
12	S/PDIF	Fiber Optic	Digital audio output (Optical)
13	VIDEO	RCA cinch	Composite video output
14	AUDIO L	RCA cinch	Left audio output
15	AUDIO R	RCA cinch	Right audio output
16	Y	RCA cinch	Component video output(Y)
17	Pb	RCA cinch	Component video output(Pb)
18	Pr	RCA cinch	Component video output(Pr)
19	S-VIDEO	MINI-DIN	S-VHS Output

4.3 Remote controller




- 1 POWER** : To turn the receiver On/Off.
- 2 MUTE** : To turn the sound On/Off.
- 3 MOSAIC** : To display multiple pictures.
- 4 SLEEP** : To set the STB off after minutes.
- 5 FREEZE** : To pause the video. Press again to resume the video.
- 6 ZOOM** : To zoom In/Out.
- 7 TV/RADIO** : To switch between TV and Radio.
- 8 SUBTITLE** : To show the subtitle contents if subtitle is transmitted.
- 9 AUDIO** : To show the Multi-language audio track, the stereo-mono mode and subtitle information. Used for special functions in menu mode.
- 10 Numeric Keys (0-9)** : To enter numerical settings (such as channel numbers) directly.
- 11 RECALL** : To move to the previous channel. Used for special functions in menu mode.
- 12 GROUP** : To change the channel groups(Satellites or favorite groups)
- 13 MENU** : To enter or exit the main menu.
- 14 EXIT** : To exit from the present menu and move to the previous menu.
- 15 - 16 Up & Down** : To switch channels in non-menu mode and move the cursor up/down in menu mode.
- 17 - 18 Left & Right** : To change the volume level in non-menu mode and modify a setting in menu mode.

4.3 Remote controller



- 19 OK** : To show the Channel List in non-menu mode and select an item or confirm in menu mode.
- 20 INFO** : To show information about the current program. Press twice to show detail.
- 21 GUIDE** : To show the TV/Radio program guide.
- 22 PLAY** : Play Content.
- 23 PAUSE** : Pause playback.
- 24 FILELIST** : To display the filelist.
- 25 STOP** : Stop Playback.
- 26 REC** : Start recording.
- 27 RWD** : Playback in rewind mode.
- 28 FWD** : Playback in forward mode.
- 29 SLOW** : Playback in slow mode.
- 30 ADVANCE** : Go to live channel.
- 31 - 34 Color Key** : Select the option such as View List, Select Disk, Rename.
- 35 V.FORMAT** : To switch the resolution of video output.
- 36 Wide** : To select a TV aspect ratio with Pan Scan or Letter-Box(4:3) (Full screen or Pillar box(16:9).
- 37 - 38 Page Up/Down** : To move to the next or previous page when many pages are available.

4.4 Front Display




1		Indicates Power (On/Off) mode
2		Lights when the signal comes in via satellite dish
3		Lights when the current channel is recording
4		Lights when Time-Shift Mode is set to enable
5		Lights when Time-Shift Mode is set to enable
6		Lights when a timer setting in standby mode
7		Lights when the signal is HD
8		Lights when USB devices is connected
9		Indicates the current channel is set to Lock mode
10		Lights when the current channel is Dolby audio format
11		Lights when the current sound is set to Off
12		Feature not supported
13		Feature not supported
14		Lights when Mp3 player is enabled
15		Lights when loop mode is setting in Mp3 player
16		Lights when the current channel is Radio mode
17		Lights when the current channel is TV mode
18		Lights when the signal comes in via TV Antenna
19		Indicates when the current playback mode in file list
20		Lights when Media & Recorded file is playing and revolving on the outer circle
21		Indicates the resolution of video output
22		Indicates the Progressive or interlaced scanning mode

How to Connect

5.1 When Connecting IRD to TV with AV connectors

- 1 Connect the TV antenna to TV ANT IN
- 2 Connect the Video and Audio of TV to the Video and Audio. Connect Red and White connector to Audio R and Audio L, and Yellow into Video port respectively
- 3 Connect the Component Video of your TV to Component Video for best quality: connect the Y, Pb and Pr of your TV to Y, Pb and Pr respectively
- 4 Connect your satellite dish



6.1 Getting Started


After your receiver is powered on, proceed with installation as follows :

(1) Installation Wizard

1) A/V Output Setting

This sub menu allows you to set audio/video output setting. <Figure 6-1-1>

- **SCART** : Select the SCART output. (CVBS/RGB)
- **Screen Format** : Select the screen format. (16:9/4:3)
- **Display Format** : Select the TV aspect ratio(Full Screen/Pillar Box, Letter Box/Pan Scan)
- **Video Format** : Select the Scanning type(Interlaced, Progressive)
- **SPDIF** : Select the Audio output type (Dolby/PCM)




<Figure 6-1-1>

6.1 Getting Started

2) Time Setting

This sub menu allows you to set your local time, wake up time, wake up channel and sleep time. <Figure 6-1-2>

- **GMT Usage** : If you set ON, local time is determined by adjusting the differences from GMT (Greenwich Meantime) according to your location.
- **Current Date** : If GMT Usage ON, this date is determined by GMT. If GMT Usage OFF, you can modify this by pressing the button. If you set OFF, receiver doesn't refer to GMT. Local time is determined by adjusting current date and current time.
- **Current Time** : If GMT Usage ON, this time is determined by GMT. If GMT Usage OFF, you can modify this by pressing the NUMERIC button.
- **Local Offset** : If GMT Usage ON, Local time is GMT time + Local Offset.
- **Summer Time** : you can set the summer time mode (Off/Last Sun in Oct~Mar/First Sun in Oct~Mar/Mar~Oct)
- **Wake Up Mode** : You can set the cycle of the wake up mode (Off/Once/Daily/Mon~Fri)
- **Wake Up Time** : You can set wake up time by pressing the NUMERIC button on the remote.
- **Wake Up Channel** : You can set wake up channel by pressing the button on the remote.
- **Sleep Mode** : You can set the cycle of the sleep mode (Off/Once/Daily/Mon~Fri)
- **Sleep Time** : You can set sleep time by pressing the NUMERIC button on the remote




<Figure 6-1-2>


6.1 Getting Started

3) Dish Setup

- ❶ Press the MENU button to display the main menu.
 - ❷ Use / and / to move in the menu.
 - ❸ Press on 'Dish Setting'. The following window will appear. <Figure 6-1-3>
- * **Note** : Enter a 4-Digit password if need arise. The default password is '0000'.



<Figure 6-1-3>




<Figure 6-1-4>

- ❹ Select the item that you want to edit, and set its parameters as desired. <Dish Setting>
 - **Satellite** : Select any satellite by pressing / buttons.
 - **Frequency** : If the default TP frequency is not appropriate, you can select another TP frequency at which to check for signal
 - **LNB Power** : Select among ON/OFF/13V/18V.
 - **LNB Type** : Select among Universal/OCS/Single.
 - **LNB Freq** : Set the frequency of the LNB oscillator.
 - **22KHz** : When not AUTO, set the signal path from LNB or switch by selecting a control signal among 0/22KHz.
 - **DiSEqC 1.0 / 1.1** : Select DiSEqC protocol among OFF/1.0/1.1 as appropriate for your configuration. <Figure 6-1-4>
 - **DiSEqC Motor** : Select DiSEqC protocol among OFF/1.2/USALS as appropriate for your Motor. <Figure 6-1-5>
 - **Rename** : Change the name of satellite.(if selected Russian Language that Support Russian keypad).
 - **Beep On/Off** : Beep Sound as signal level.
- ❺ **Auto Scan** : Press Green button the remote to begin Auto Scan.

6.1 Getting Started

(When the DiSEqC Motor parameter is set as 1.2)



<Figure 6-1-5>

- **Motor Step** : Select Motor Step
- **Move** : Move the dish position to west/east by pressing / buttons.
- **Go To** : Go to the position of the saved satellite.
- **Motor Control** : Control motor by press button of the remote.
- ** **Recalculate** : Recalculate the position of all other saved satellites relative to the known position.
- ** **Reset System** : Reset the position of all saved satellites.
- ** **Goto Reference** : Move the dish to the 0 position.
- ** **Set West Limit** : Edit & Save west limit by pressing / or buttons.
- ** **Set East Limit** : Edit & Save east limit by pressing / or buttons.
- ** **Enable Limit** : Enable the saved east and west limit.
- ** **Disable Limit** : Disable east and west limit.
- ** **Save** : Save the current setting of DiSEqC 1.2 system.

6.1 Getting Started

(When the DiSEqC Motor parameter is set as USALS)


- **Move** : Move the dish position to west/east by pressing / buttons.
- **Motor Control** : Control motor by press button of the remote.
- ** **Goto Reference** : Goto reference by pressing button.
- ** **Set West Limit** : Edit & Save west limit by pressing / or buttons.
- ** **Set East Limit** : Edit & Save east limit by pressing / or buttons.
- ** **Enable Limit** : Enable the saved east and west limit.
- ** **Disable Limit** : Disable Limit by pressing button.
- ** **Save** : Save the current Setting of USALS system.
- **Sat Degree** : Displays the current degree of the selected satellite. Edit degree by pressing / buttons and numeric buttons.
- **Position Setting** : Select position setting by pressing button.
- ** **Goto Reference** : Move the dish to the 0 position.
- ** **Antenna Longitude** : Edit antenna longitude by pressing / buttons and numeric buttons.
- ** **Antenna Latitude** : Edit antenna latitude by pressing / buttons and numeric buttons.
- **Go To** : Save the current setting of USALS System.

6.1 Getting Started


4) Satellite Channel Search

► Auto Scan <Figure 6-1-6>

- ❶ To select more than one satellite, press the button when the selection bar is positioned on the satellite.
- ❷ Press on the names of the satellites that you want to scan under 'Satellite List'. Press the EXIT button to close the 'Satellite List'.
- ❸ Press / and set the 'Search Type' and 'Network Search' parameters.
 - **Search Type** : Decide for which channels to search (All channels/ Free channels only/ TV channels only).
 - **Network Search** : Set ON to find more transponders (frequencies) through a Network Information Table (NIT) scan. That is, when the broadcaster is sending a NIT through a given transponder, the receiver will also scan for transponders listed in the NIT and not otherwise recognized. (this can happen when a transponder is new)
- ❹ Press **RED button** under 'SCAN' to scan the selected satellites. <Figure 6-1-7>



<Figure 6-1-6>





<Figure 6-1-7>


6.1 Getting Started

► Manual Scan <Figure 6-1-8>


- ❶ Select a transponder.
- ❷ To change a transponder's information (Frequency, Symbol Rate), use the **NUMERIC** buttons.
- ❸ To add a new transponder, press the **GREEN** button.
- ❹ To delete a transponder, press the **YELLOW** button with the cursor next to the Frequency parameter.
- ❺ To search a transponder, set its different parameters and **RED** button.

► Package Identifier (PID) Scan <Figure 6-1-9>

- ❶ Select a transponder.
- ❷ To change a transponder's information (Frequency, Symbol Rate), use the **NUMERIC** buttons.
- ❸ To add a new transponder, press the **GREEN** button.
- ❹ To delete a transponder, press the **YELLOW** button with the cursor next to the Frequency parameter.
- ❺ To search a transponder, set its different parameters and press  / . You can search a specific channel of the transponder by setting its PID data (Video, Audio and PCR).



<Figure 6-1-8>




<Figure 6-1-9>

*** Note :** If you cannot access programs after correctly completing a scan procedure, please contact your seller or your installer.

6.1 Getting Started

► Blind Scan<Figure 6-1-10>

- ❶ To change a transponder's Frequency use the **NUMERIC** buttons.
- ❷ Select a range of **Symbol Rate**(FULL/7.5M Over/7.5M Under/3.7M Under/DETAIL).
- ❸ Select a **Polarization**(V/H/ALL).
- ❹ Select a Search Type(All/FTA/TV).
- ❺ Press **RED** to begin the scan.






<Figure 6-1-10>

5) Terrestrial Channel Search


Through this function, the receiver searches for all the available channels and saves them in memory.

► Auto Scan <Figure 6-1-11>

- ❶ To select a Terrestrial, press the  button when the selection bar is positioned on the satellite.
- ❷ Press  on the names of the satellites that you want to scan under 'Satellite List'. Press the **EXIT** button to close the 'Satellite List'.
- ❸ Press **RED** to begin the scan. <Figure 6-1-12>



<Figure 6-1-11>




<Figure 6-1-12>

6.1 Getting Started

► Manual Scan <Figure 6-1-13>

- 1 To change a scan mode, use / , . Select a Manual Scan item.
- 2 Select the frequency you want to search for select the frequency by pressing / , , or specify a frequency by entering the frequency with the number keys.
<Figure 6.1.14>
- 3 Press **RED** to begin the scan. <Figure 6-1-14>




<Figure 6-1-13>



<Figure 6-1-14>

► Package Identifier (PID) Scan <Figure 6-1-15>

- 1 Select a transponder.
- 2 To change a transponder's information (Frequency, Bandwidth), use the / buttons.
- 3 To search a transponder, set its different parameters and press / . You can search a specific channel of the transponder by setting its PID data (Video, Audio and PCR).



<Figure 6-1-15>


6.1 Getting Started

(2) To View Program

1) Channel Selection

You can use / to navigate between channels until you find the channel you want.

- If you know the channel number, you can enter it with the **NUMERIC** buttons and wait 2 seconds until the channel is changed.
- If you know the channel name or transponder or CAS, you can press to display the channel list <Figure 6-1-16>











<Figure 6-1-16>


- 1 Detailed information about the selected channel will be displayed. (Satellite Name, Frequency(Polar) and Channel Name)
 - 2 You can use the following buttons to navigate between channels:
 - / : Moves one channel up/ down.
 - / : Moves one page up / page down.
 - **RED** : Press RED button on the remote to use channel sorting.
- ** **ALL** : Shows all channels in the current group.
 ** **A~Z** : Shows all channels sorted alphabetically.
 ** **TP** : Shows all channels sorted by Transponder.
 ** **CAS** : Shows all channels sorted by CAS system.
- 3 Press when the selection bar is positioned on the desired channel.

(3) Electronic Program Guide

1) EPG

This sub menu allows you to access the electronic program guide when available.







- ❶ Press the **EPG** button to display the guide menu. <Figure 6-1-17>
- ❷ Press  /  to see the previous/next guide.
- ❸ Press  / ,  /  to select another channel. <Figure 6-1-17>
- ❹ Press  to watch the selected channel and access its EPG data. If you press  in the right side of the screen (Event display list).
 - If the current time EPG is selected, you will return to the previous menu and get signal from the selected channel.
 - If a future time (next) EPG is selected, the selected program will be reserved and the event color will change.
- ❺ You can select TV or Radio channels by pressing the **TV/RADIO** button
- ❻ You can choose a channel list group by pressing the **GROUP** button.
- ❼ You can access the timer menu by pressing the **RED** button. <Figure 6-1-17>




<Figure 6-1-17>


2) Timer

This sub menu allows you to set the on/off time of your receiver.


- ❶ This sub menu allows you to set on/off times of your receiver. To display the timer menu, press the RED button while in the guide menu. <Figure 6-1-18>
- ❷ Press  /  to select a timer's parameter.
- ❸ Press  /  to change the parameter.
 - **Timer No** : Select the timer that you want to modify. (1 - 8)
 - **State** : Select the timer frequency. (off/once/daily/weekly)
 - **Date** : Press  to display a Calendar pop-up; Select a date
 - **Start Time** : Input the time for your receiver power-on; use the NUMERIC buttons
 - **End Time** : Input the time for your receiver power-off; use the NUMERIC buttons
 - **Channel** : Press  to display a Channel list pop-up; Select a channel



<Figure 6-1-18>

- If you want to record a program in the right side of the screen, you can select a program by using . The selected program will be reserved and the event color text will change to red. <Figure 6-1-19>.
- You can also see change the timer menu.



*** It is worked when a USB device is connected.**



<Figure 6-1-19>

(4) Other Functions of Remote Control

► Volume Control

- 1 While watching a program, press  /  control the volume.
- 2 You can press the **MUTE** button to remove the sound of the program: the mute icon will be displayed. Press the **MUTE** button again to turn the sound back on.

► Channel Information

- 1 You can press the **INFO** button to display the information banner for a few seconds.
- 2 If you then press the **INFO** button again, a detailed banner will be displayed.

► TV/ RADIO switching

You can press this key to change from a TV channel to a Radio channel or vice versa.

► RECALL

Press this key to return to the previous channel.

► Audio

Press to adjust the subtitle and/or audio status of the current channel:

- **Audio Mode** : Select between, Stereo/Mono-Left/Mono-Right
- **Audio Track** : Select between tracks available in this program
- **Audio Level** : Select between, Low/Medium/High

► FREEZE

You can press this key to freeze the video. Press it again to resume the video.

► GROUP

When watching TV or listening to Radio, you can press this button to view the list of satellites and/or favorite channel groups.

Only registered satellites and favorite groups are displayed.

► Multi Picture Display <Figure 6-1-20>



You can press the **MOSAIC** button to display multiple pictures; you can choose the number of pictures such as 1X2, 2X2, 2X3 or 3X3.



<Figure 6-1-20>

► ZOOM

You can press to zoom in the video. <Figure 6-1-21>

- 1 Press the PAUSE button and press . You can zoom in sections of Freezed Video <Figure 6-1-22>
- 2 While watching a program, press . You can zoom in sections of playing video.
- 3 To cancel the freeze status, please release the zoom status.



<Figure 6-1-21>




<Figure 6-1-22>


6.1 Getting Started


► Subtitle <Figure 6-1-23>

You can press  to select the subtitle language of current channel.

► SLEEP <Figure 6-1-24>

You can set the your receiver to turn off after a few minutes. Press  to set the sleep timer.

- To cancel the sleep timer, please press  until you set time as "0 min".
(Disable, 10, 20, 30, 60, 100, 120 Minutes)



<Figure 6-1-23>



<Figure 6-1-24>

► V.FORMAT <Figure 6-1-25>

You can press  to change the video resolution Select between, 1080i → 720p → 576p → 576i

► WIDE <Figure 6-1-26>

You can press  to change the TV aspect ratio.

- **4:3** : Pan-Scan or Letter-Box

- **16:9** : Full-Screen or Pillar-Box



<Figure 6-1-25>



<Figure 6-1-26>

6.2 System Setting

1) Time Settings

This sub menu allows you to set your local time, wake up time, wake up channel and sleep time.

- See **(6.1 Getting Started 4) Time Settings)** for detailed description.

2) Timer Manager

This sub menu allows you to set the on/off time of your receiver.

❶ This sub menu allows you to set on/off times of your receiver. To display the timer menu, press the **RED** button while in the guide menu. <Figure 6-2-1>

❷ Press  /  to select a timer's parameter.

❸ Press  /  to change the parameter.

- **Timer No** : Select the timer that you want to modify. (1- 8)


- **State** : Select the timer frequency. (off/once/daily/weekly)

- **Date** : Press  to display a Calendar pop-up; Select a date

- **Start Time** : Input the time for your receiver power-on; use the **NUMERIC** buttons

- **End Time** : Input the time for your receiver power-off; use the **NUMERIC** buttons

- **Channel** : Press  to display a Channel list pop-up; Select a channel



<Figure 6-2-1>

3) OSD Setting

This submenu allows you to set the menu language, OSD transparency and Information and Volume timeouts. <Figure 6-2-2>

- **Transparency** : Set the OSD transparency of the menu. (1% ~ 100%)
- **Information Timeout** : Select the display duration of the information banner. (1, 2, 3, 5 or 10 seconds)
- **Volume Timeout** : Select the display duration of the volume box. (1, 2, 3, 5 or 10 seconds)



<Figure 6-2-2>


4) Parental Control

This submenu allows you to set password options and to lock or unlock access to menus

* **Note** : PIN code and password are the same). <Figure 6-2-3>

- **Receiver Lock** : Set ON to require entering a PIN code at powering on.
- **Install Lock** : Set ON to require entering a PIN code to access the installation menu.
- **Channel Lock** : Set ON to require entering a PIN code to access the channels menu.
- **Lock Channel Confirm** : Set ON to require entering a PIN code to access a locked channel.
- **Age Limit** : Set to prevent children or unauthorized people from watching programs. Select among (Free/ 8 above/12 above/15 above/18 above). When program information (age limit) is available from broadcaster and this age limit exceeds the selection, a PIN code is required to access the channel/program.
- **New Password** : Enter the new password that you want to set.
- **Verify Password** : Enter the new password again for confirmation.

* **Note** : The default password is '0000'.




<Figure 6-2-3>

5) Language Setting

This submenu allows you to specify the audio/video output <Figure 6-2-4>

- **Menu Language** : Set the default Menu language.
- **Audio Language** : Set the default audio language when selecting a channel.
- **Subtitle Language** : Set the default subtitle language.



<Figure 6-2-4>

6) A/V Output Setting


This sub menu allows you to set audio/video output setting.

See (6.1 Getting Started 3) A/V Output Setting) for detailed description.

7) Front Display Setting

This submenu allows you to specify the audio/video output <Figure 6-2-5>

- **Blue Light** : Trun the blue light ON/OFF.
- **Text Moving** : Turn the text moving ON/OFF.
- **Channel Number** : Turn the channel number ON/OFF.



<Figure 6-2-5>

8) IP Setting

If the Network supports DHCP , IP settings can be allocated automatically. If the Network does not support DHCP, the Addresses must enter manually (Static IP).<Figure 6.2.6>

- **DHCP Usage** : On/Off to receive IP settings automatically
- **IP Address** : Here enter the IP address
- **Subnet Mask** : Here enter Subnet Mask Number from your Network
- **Gateway** : Here enter IP address of Gateway (e.g. router)
- **DNS** : Here Enter IP address of main DNS Server
- **Mac Address** : Mac Address display




<Figure 6-2-6>


- **Firmware update** : Support download from a LAN.

- 1 **BLUE** button, appear input target IP address.
- 2 button to connect after input a target IP.
- 3 Choose a update software and button for downloading.

* **Note** : Have to run PC tool before connect PC.



<Figure 6-2-7>







<Figure 6-2-8>


6.3 Channel Manager

1) Set Favorites

This submenu allows you to set up favorite groups of channels. You can select **TV** or **Radio** channels in an alternative way by pressing the **TV/RADIO** button. The receiver supports 16 favorite groups.


- 1 Press  on 'Set Favorites'. The list of groups will be displayed. <Figure 6-3-1>
- 2 Press  /  and  to choose a group. The following menu will be displayed. <Figure 6-3-2>

If you want to change the name of a favorite group, press the **RED** button.

- 3 Press  to add (or remove if previously added) the selected channel to/from the favorite channel group.
- 4 Press the **EXIT** button to return to the previous menu.



<Figure 6-3-1>





<Figure 6-3-2>


6.3 Channel Manager

2) Lock Channels

This submenu allows you to lock channels to control access to them. Once a channel is locked, you will be asked to enter a password whenever you try to watch it. You can select TV or Radio channels in an alternative way by pressing the **TV/RADIO** button. You can choose a channel list group by pressing the **GROUP** button.

If you set 'Lock Channel Confirm' (refer to <6.2>security setting) to OFF, you will not be asked to enter a password even if the channel is locked.

- 1 Press  on 'Lock Channels'. The following menu will be displayed. <Figure 6-3-3>
- 2 Press  on the channel that you want to lock/unlock; the lock icon will be displayed/removed.
- 3 Press the **EXIT** button to return to the previous menu.



<Figure 6-3-3>








6.3 Channel Manager


3) Move Channels

This submenu allows you to move channels.

You can select TV or Radio channels in an alternative way by pressing the **TV/RADIO** button.

You can choose a channel list group by pressing the **GROUP** button.

- 1 Press  on 'Move Channels'. The following menu will be displayed. <Figure 6-3-4>
- 2 Press  on the channel that you want to move; a 'move' icon will be displayed.
- 3 Use the  /  ,  /  **NUMERIC** buttons to move the selected channel.
- 4 Press  again to place the channel.
- 5 Press the **EXIT** button to return to the previous menu.





<Figure 6-3-4>


6.3 Channel Manager

4) Delete Channels

This submenu allows you to delete channels. You can select TV or Radio channels in an alternative way by pressing the TV/RADIO button. You can choose a channel list group by pressing the **GROUP** button.

*** Note : Be careful! If you delete a channel, you will not be able to access it again until you rescan.**

- 1 Press  on 'Delete Channels'. The following menu will be displayed. <Figure 6-3-5>
- 2 Press  on the channel that you want to set/unset for deletion; the delete icon will be displayed/removed.
- 3 Press the **INFO** button to delete all channels in the current list; you will be asked to enter your password.
- 4 Press the **EXIT** button to return to the previous menu and confirm deletion.



<Figure 6-3-5>


6.3 Channel Manager

5) Skip Channels

This submenu allows you to skip channels. Once a channel is set to be skipped, it will be whenever you navigate channels using / in non-menu mode. You can select TV or Radio channels in an alternative way by pressing the **TV/RADIO** button. You can choose a channel list group by pressing the **GROUP** button.

*** Note : You can still access a 'skipped' channel if you enter its number using the NUMERIC buttons in non-menu mode.**

- 1 Press on 'Skip Channels'. The following menu will be displayed.<Figure 6-3-6>
- 2 Press on the channel that you want to skip/un-skip; the skip icon will be displayed / removed.
- 3 Press the **EXIT** button to return to the previous menu.



<Figure 6-3-6>

6.4 Installation

1) Dish Setting

Select the item that you want to edit, and set its parameters as desired. <Dish Setting> See **(6.1 Getting Started 3) Dish setup)** for detailed description.

2) Channel Search


Through this function, the receiver searches for all the available channels and saves them in Memory. Chose Auto Scan to search using transponders (frequencies) in memory, or chose Blind Scan to look for new satellite/transponders. See **(6.1 Getting Started 4) Channel Search)** for detailed description.

3) Data Transfer

This submenu allows you to transfer the software from a receiver to another receiver. You can select and transfer Firmware/ Channel Data. <Figure 6-4-1>

- **Firmware** : Transfer the firmware of a receiver to another receiver.

- **Channel Data** : Transfer the channel data of a receiver to another receiver.




<Figure 6-4-1>

6.4 Installation

4) Database Reset

This submenu allows you to restore the factory set values (useful when encountering problems after changing settings). <Figure 6-4-2>

- **Delete Radio Channels** : Erase all radio channels in the database.
- **Delete Scramble Channels** : Erase all scramble channels in the database.
- **Delete All Channels** : Erase all channels.
- **Factory Set** : Erase all channels and restore the factory default settings.




<Figure 6-4-2>

5) System Information

You can check the current information about your receiver such as receiver model name, S/W (software) version, H/W (hardware) version, manufacturing date, etc. <Figure 6-4-3>

*** Note :** This information is useful to download new software and/or repair the receiver.




<Figure 6-4-3>

6.5 Utils

1) Calendar




This submenu allows you to use a calendar on the screen <Figure 6-5-1>




<Figure 6-5-1>

2) Calculator

This submenu allows you to use a calculator on the screen. <Figure 6-5-2>











- You can switch between Hex (Hexadecimal) and Dec (Decimal) basis for arithmetic with the **RED** button of the remote control unit.
- Use the Numerical and the  /   buttons on the remote control unit.




<Figure 6-5-2>


3) MP3 Menu

This submenu allows you to play various MP3 files, view JPG files or download a new software by connecting your USB flash drive.

- ❶ Select the MP3 file you want to play back by using  / ,  in the file list. <Figure 6-5-3>
- ❷ Press the EXIT button to hide the file list. You can then select an option using  / , . <Figure 6-5-4>
- ❸ You can then change the volume by pressing  / .
- ❹ Press  on **LIST** to display the MP3 file list.
- ❺ Press  on **INFO** to display information about the selected MP3 file.
 - **FILELIST** : Shows/Hides the MP3 file list
 - **INFO** : Shows information about the MP3 file you selected.
 - **YELLOW** : Choose the Hard disk volume or usb device with USB hub.







<Figure 6-5-3>



<Figure 6-5-4>

4) *JPG menu*

- ① Press  /  to select a picture. <Figure 6-5-5>
- ② Press  to show the picture you want to display.
 - **RED** : Sets the time interval between slides.
 - **GREEN** : Selects slide show.
 - **YELLOW** : Choose the Hard disk volume or usb device with USB hub.
 - **FILELIST** : Shows/Hides the JPEG file list.




<Figure 6-5-5>

5) Data Transfer menu

- ❶ Select the software you want to download by using 🖱️ / 🖱️ in the list <Figure 6-5-6>
- ❷ Press ⏻ to start software downloading
 - **YELLOW** : Choose the Hard disk volume or usb device with USB hub.
 - ~~**FILELIST** : Shows/Hides the JPEG file list~~


*** Warning : Please do not switch off your receiver before software downloading is completed.**




<Figure 6-5-6>

6) Disk Manager

- **Default Disk** : Set the pvr disk.
- * **Note** : If External SATA is connected, External SATA can be captured in "volume0". Otherwise, one of other disks can be captured in "volume0"
- **Disk Information** : Choose the Hard disk volume or usb device with USB hub. You can view a information of usb devices (used size, total size, free size)
<Figure 6-5-7>
- **Chck Disk** : Choose the Hard disk volume or usb device with USB hub. You can check the usb devices. <Figure 6-5-8>




<Figure 6-5-7>



<Figure 6-5-8>

- **Format Disk** : You can format the usb devices. <Fig 6-5-9>



<Figure 6-5-9>

7) File Manager

- 1 Press **YELLOW** button for connect PC.
 - 2 Press button after input IP address of PC.
 - 3 Press button after choose target.
- * **Note** : Have to run PC tool before connect PC.




<Figure 6-5-10>




<Figure 6-5-11>

- 4 Press Right button and Press **RED** for chooses files.
- 5 Press button to choose Copy/Move/NewFolder/Delete/Rename after press **MENU** button.
- 6 If select copy or move, press button to move target for paste.
- 7 Press **MENU** button to paste target.
- 8 Select a Paste for Copying or Moving files.












<Figure 6-5-12>



<Figure 6-5-13>

1) Tetris

- 1 Press  on 'Tetris'. The following menu will be displayed. <Figure 6-6-1>
- 2 You can choose a skill level using  / .
- 3 Press  to start the game <Figure 6-6-2>, or press the EXIT button to return to the previous menu.
- 4 Press  to rotate a block.
- 5 Press  /  to move a block.
- 6 Press  to drop a block.
- 7 You can see the next block in the top-right small window.
- 8 Press the **EXIT** button to quit the game











<Figure 6-6-1>




<Figure 6-6-2>

2) Sokoban

How to play Sokoban: you have to push the balls to their correct positions. The balls can only be pushed, never pulled, so you have to be careful not to push them into a corner where you can't get them out from. You can only push one ball at a time.

- 1 Press  on 'Sokoban'. The following menu will be displayed. <Figure 6-6-3>
- 2 You can choose a skill level using  / .
- 3 Press  to start the game <Figure 6-6-4>, or press the **EXIT** button to return to the previous menu.
- 4 Press , , , or  to move.
- 5 Press the **RED** button to undo the previous move. You can undo only one step.
- 6 Press the **GREEN** button to restart the game.
- 7 Press the **YELLOW/BLUE** buttons to jump to the previous/ next level. You can jump only between completed levels.
- 8 Press the **EXIT** button to quit the game.












<Figure 6-6-3>



<Figure 6-6-4>

3) Snake

- 1 Press  on 'Snake'. The following menu will be displayed. <Figure 6-6-5>
- 2 You can choose a skill level using  / .
- 3 Press  to start the game <Figure 6-6-6>, or press the **EXIT** button to return to the previous menu.
- 4 Press , , , or  to move.
- 5 Pass through the **GREEN** icon to increase your score; the length of the snake increases.
- 6 Pass through the **RED** icon to decrease the snake's length.
- 7 Avoid the **BLACK** icons. If you hit a **BLACK** icon (block), the game ends.
- 8 Press the **EXIT** button to quit the game.



<Figure 6-6-5>




<Figure 6-6-6>

1) CAM Initializing

To enjoy scrambled channels, you will need a Common Interface Conditional Access Module (CAM) and a Smart Card from the service provider (program distributor). If you are subscribing to services from more than one service provider, you will need a Smart Card from each one, and may even need different CAMs (depending on the DVB Common Interface standard each uses). Since a Smart Card is connected to a single service provider, a limited range of channels will be available via it.

*** Note : Without the CAM and the smart card, you can watch only Free-to-Air programs.**

- ❶ Insert a CAM into a receiver's slot designed for it, and a Smart Card into the CAM.
- ❷ The message 'CAM Initializing' will appear on the screen. <Figure 6-7-1>
- ❸ After the message 'CAM Initializing' has disappeared, you can select the channel that you want to watch.




<Figure 6-7-1>

2) The Status of the CAM

- ❶ You can access detailed information about the CAM using the / keys in the Main Menu to select 'CI' and pressing . <Figure 6-7-2>
- ❷ Proceed with further instructions displayed on the screen to check more detailed information depending on the CAM in use.

*** Note : Further detailed information is not mentioned in this manual since the information depends on the CAM in use.**




<Figure 6-7-2>

1) Card Initializing

To Enjoy CONAX CAS7 scrambled channels, you will need a Smart Card from the service provider (program distributor). If you are subscribing to services from more than one service provider, you will need a Smart Card from each one. Since a Smart Card is connected to a single service provider, a limited range of channels will be available via it.

*** Note : Without the Smart Card, you can watch only Free-To-Air programs.**

- ❶ Insert the Smart Card into the receiver's slot designed for it.
- ❷ The message 'Smart Card Initializing' will appear on the screen. <Figure 6-8-1>
- ❸ After the message 'Smart Card Initializing' has disappeared, you will be able to watch the channels offered by the service provider.




<Figure 6-8-1>

2) The Status of the Smart Card

- ❶ You can access detailed information about the Smart Card using the / keys in the Main Menu to select 'CA' and pressing . <Figure 6-8-2>
- ❷ Proceed with further instructions displayed on the screen to check more detailed information depending on the Smart Card in use.







*** Note: Further detailed information is not mentioned in this manual since the information depends on the Smart Card in use.**




<Figure 6-8-2>

1) File List

► File Playback

- ① Press  to show the file list. Select the file you want to play back by using  /  , .
 - ② Press . In the left side of screen, detailed information about the selected file will be displayed. (Recorded Date/Time, Used size, Total Size) <Figure 6-9-1>
- To see a full screen, press  once more. And then the following time-bar will appear. <Figure 6-9-2>




<Figure 6-9-1>






<Figure 6-9-2>

► Edit Menu

You will be asked to enter a password whenever you try to enter it. Press . The pop-up menu for selection will appear <Figure 6-9-3>.


Select the item that you want to edit, and set its parameters as desired

- ① Normal Mode : Press  on the file that you can see the preview of a selected file.
- ② Lock Mode : Press  on the file that you want to lock/unlock.
- ③ Delete Mode : Press  on the file that you want to delete.

- **GREEN** : Select between, File Mode ↔ Dir Mode






- **BLUE** : Shows all sorted files. Select between, Sort by name ↔ Sort by time.


*** If you set 'Channel Lock' (refer to <Figure 6.2.4>security setting) to OFF, you will not be asked to enter a password even if the channel is locked.**



<Figure 6-9-3>

2) Play List

- ① While watching a program, press  to show the play list. <Figure 6-9-4>
 - ② While recording a program, press  to show the play list. <Figure 6-9-4>
 - ③ Select the file you want to play back by using  / , . And then the following time-banner will appear. <Figure 6-9-5>
- **GREEN** : Select between, File Mode → Dir Mode
 - **YELLOW** : Shows all sorted files. Select between, Sort by name → Sort by time



<Figure 6-9-4>




<Figure 6-9-5>



3) Trick Mode

You can operate the trick mode while you are playing the recorded files. These functions are available in playback mode or time-shift mode powerfully.



▶ PLAY

This button will display a time- banner. If you want to show the play list while playing the file by using .


▶ PAUSE

This button will pause the playing file until you play again with  or . <Figure 6-9-6>

▶ ADVANCE

- If the time-shift mode is enabled, You can press  to jump the live program.
- If the recording mode is enabled, You can press  to jump to the current recording position.

▶ FF(Fast Forward)

- When playing the file, you can press  to adjusting the playing speed.<Figure 6-9-7>
- The speed will change to x2, x4 and x8.




<Figure 6-9-6>




<Figure 6-9-7>

► RWD(Rewind)

When playing the file, you can press  to adjusting the playing speed. <Figure 6-9-8>
The speed will change to x2, x4 and x8.

► Slow(1/2x, 1/4x)

When playing the file, you can press  to adjusting the playing speed. <Figure 6-9-9>





<Figure 6-9-8>





<Figure 6-9-9>

► Jump

- You can locate the control position to the desired position by using the  / .
- If you press this key continuously, You can locate the control position to the desired position very quickly.

► Skip


- You can skips and forward in 15 seconds using the .
- You can skips and backward in 15 seconds using the .

► Bookmark

To mark a specific place in a file for later retrieval. <Figure 6-9-10>







- **RED** : Press this button and red small triangle cursor will be placed at that position. If you want to delete the bookmarked position, press a this button once more when red small triangle cursor appear.
- **GREEN** : Press this button and the current position will jump to the previous bookmarked position and playback starts from this point.
- **YELLOW** : Press this button and the current position will jump to the next bookmarked position and playback starts from this point.

*** Note : The maximum number of the bookmark is 20 in a file.**




<Figure 6-9-10>

4) Instant Recording

- ❶ You can record a current channel by using . If you then press , a time-banner will be displayed. <Figure 6-9-11>
- ❷ Press  once more. The following picture shows that you can select item when you record a current channel. <Figure 6-9-12>
 - **Channel** : It shows a current channel.
 - **Name** : It shows a current recording name.
 - **Duration** : You can change the duration of recording time by using the  / . And current recorded time appear.
 - **Stop** : If you stop the recording, Press .




<Figure 6-9-11>




<Figure 6-9-12>


- * **Note** : 1. Do not remove the USB device while recording a program.
 2. You can't change to another channel while recording a program.

5) Timer Recording


This function is available when usb device is connected. You can choose a channel to record the Program Guide menu by using . (Refer to 6.4 Electric Program Guide, 2)Timer)

6) Time Shift

- ❶ If you want to pause and resume live TV channel, press **PAUSE** button. The default time of Time-Shift is 30 min in your STB. <Figure 6-9-13>
- ❷ If you want to resume live TV channel, press **PLAY** button. <Figure 6-9-14>
- ❸ The trick-mode operations are provided. If you want to jump to live channel, please press .



<Figure 6-9-13>



<Figure 6-9-14>

Trouble Shooting

There may be various reasons for the abnormal operation of the unit. Therefore, if the unit does not work properly, check it according to the procedures shown in the table below:

Problem	Possible causes	Remedy
VFD on front panel does not light.	AC power cord is not connected.	Make sure that power cord is connected properly into the power socket. Make sure power switch is on.
No Picture or sound	The video/audio output of the receiver with TV is connected.	Make sure that video/audio cable is connected to the TV.
	The aerial is not connected to the receiver.	Make sure that the aerial is connected properly to the receiver.
	Menu setting is not done properly.	Make sure that menu setting is done properly on each menu. If you are not sure about proper menu setting, please contact your local dealer.
Black-and-white screen	Your TV mode is different from broadcasting mode.	Use TV of same mode. Use the NITSC/PAL converter connected to the receiver and TV.
The remote controller is not working.	Battery exhausted. Remote controller is incorrectly aimed.	Change the batteries of remote control. Aim the remote control at the Receiver correctly.

Specifications

System capabilities satellite LNB/Tuner input	Fully DVB compliant	
	connector	IEC 169-24, female
	Frequency range	950MHz ~ 2150MHz
	Signal level	-65dBm ~ -25dBm
	LNB supply	DC 13/18V, max 400mA
	LNB switch control	22KHz
Demodulator	DiSEqC	Ver 1.0/1.1/1.2/USALS Compatible
	Front end	DVB-S/S2 QPSK, 8PSK
	Symbol rate	DVB-S : 2~45Msps DVB-S2 : 10~30Msps(QPSK) 10~30Msps(8PSK)
	SCPC and MCPC Capable	
	Spectral inversion	Auto conversion
TERRESTRIAL System capabilities Tuner & Channel Decoder	Input connector	IEC 169-2, Female
	Loop-through out	IEC 169-2, Male
	Frequency range	170~230MHz, 470~862MHz
	Input impedance	75 Ohms Nominal
	Signal level	7,8MHz(-78dBm~-25dBm) switchable by software
	IF Bandwidth	7,8MHz(-3dBm) switchable by software
	Waveform	OFDM
	Carrier Mode	2k and 8k hierarchical/non-hierarchical
	Code Rate	1/2, 2/3, 3/4, 5/6, 7/8
System resource	Guard Interval	1/4, 1/8, 1/16, 1/32
	Processor	32bit processor (266MHz)
	DDR SDRAM	32Mbyte X 4
	FLASH	8Mbyte
Video decoder	EEPROM	256Kbit
	MPEG 2	MPEG-2, MPEG-4, H.264
	Data Rate	up to 15M bits/s
	Resolution	1920 X 1080i, 1280 X 720p, 720 X 576i/p
	Video format	PAL
Teletext	Aspec Ratio	4:3,16:9
	DVB compliant	
MPEG Audio	MPEG 1 layer 1 &2	
	Type	Mono, Stereo, Joint Stereo
	Sampling rates	32, 44.1 and 48 KHz

Serial data interface	Connector	9pin D-sub male, Max 115K bps
	Code	NEC-IR
	Operating condition	up to 7 Meter
USB	USB Supply	DC 5V Max 500mA
	Power consumption	max 40W
	Supply voltage	100V ~ 250V
	Supply frequency	50Hz ~ 60Hz
Power supply	TV SCART	Video output(CVBS, RGB)
		Audio output(L, R)
	VCR SCART	Video output(CVBS)
		Video input(CVBS, RGB)
		Audio output(L, R)
	Video	1 X RCA cinch
	Audio L/R	2 X RCA cinch
	Component(Y/Pb/Pr)	3 X RCA cinch
	Serial data	9pin D-sub
	Digital tuner input	IEC 169 - 24
	Loop-through Digital tuner	IEC 169 - 24
	Terrestrial ant input	IEC 169 - 2
	Terrestrial ant output	IEC 169 - 2
	S/PDIF	Fiber Optic
	S-Video	Mini-DIN
	HDMI	Digital Video/Audio Output
	USB	USB A-type
	SATA	External SATA
	LAN	RJ-45

Physical Specification	Size (W X H X D)	335 X 58.5 X 247(mm)
	Weight (Net)	3 Kg



Disposal of Old Electrical & Electronic Equipment(Applicable in the European Union and other European Countries with separate collection systems)

This symbol on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. The recycling of materials will help to conserve natural resources.

For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.